Part I

Short Design Course

Chapter 1

A method for solving system design problems

This chapter outlines our approach to solving design problems. Section 1.1 gives basic facts about rational functions, which are the single most important type of functions in practical system design. The basic system and functions considered in this book are introduced in Section 1.2 and Section 1.3. A control design problem is presented in 1.4. A description of the method used in this book to solve control problems is in Section 1.5.

1.1 Rational functions

A rational function can be thought of as a function on the imaginary axis $F(j\omega)$, or as a function on the complex plane, where the notation $F(s)$ is used. If $N(s)$ and $D(s)$ are polynomials, then the rational function $F(s) = \frac{N(s)}{D(s)}$ has *relative degree* given by

$$d(F(s)) := degree(D(s)) - degree(N(s))$$

The function F is called *proper* if $d(F) \geq 0$, and *strictly proper* if $d(F) > 0$.

A function F is said to be *bounded* (on the imaginary axis) if there exists a constant $M > 0$ such that

$$|F(j\omega)| \;\leq\; M, \quad \forall \omega \in R$$

The smallest of such M is the number $||F||_\infty = \sup_{\omega \in R} |F(j\omega)|$, called the *supremum of* $|F(j\omega)|$ (See Fig. 1.1).



Figure 1.1: Plot of $|f(j\omega)|$ vs. frequency ω, where $f(s) = 1/((s-.5)^2+4)$. The dotted line marks $||f||_\infty$.

A rational function F is bounded if and only if it is proper and has no poles on the imaginary axis; the proof of this is left as an exercise. The value $||F||_\infty$ is not always attained, as the example below illustrates.

Example. The function $F(s) = s^2/(s^2-10.)$ is bounded, since $|F(j\omega)| \leq 1 \ \forall\omega$. However, for this example there is no single finite frequency ω_0 at which $|F(j\omega_0)| = 1$. In other words, the supremum is not attained.

Functions $F(s)$ that satisfy the equality

$$F(s) = \overline{F(\overline{s})}, \tag{1.1}$$

for all s, are sometimes referred to as *real* (on the real axis), and are very important in engineering. They arise as the Laplace transform of real valued functions of time. On the imaginary axis equality (1.1) becomes

$$F(j\omega) = \overline{F(-j\omega)} \tag{1.2}$$

All functions that appear in this book have this property. One can show that a rational function is real if and only if the coefficients are real numbers.

A rational function is *stable* if every pole of the function has negative real part, and the relative degree is not positive.

The usual convention is to denote the set of all rational functions that are stable and real by $\mathcal{RH}^\infty$. Note that functions in $\mathcal{RH}^\infty$ can be described as proper rational functions with real coefficients and with no poles in the closed Right-Hand-Plane RHP [1].

[1] Some of the concepts introduced here apply to other (non rational) functions as